

# MOJO, METCON, MAX SAVAGE SIZE CHART

ALL BOSS PLATES ARE MEASURED FROM CENTER OF AXLE TO CENTER OF AXLE

## MOUNTING CHART

<b>BOOT SIZE</b>	5	5.5	6	6.5	7	7.5	8	8.5	9	9.5	10	10.5	11	11.5	12
<b>PLATE SIZE</b>	5.5	5.75	5.75	6	6	6.25	6.25	6.5	6.5	6.75	6.75	7	7	7.5	7.5

## MOJO, METCON, MAX - SAVAGE BOOT SIZE

<b>BOOT SIZE</b>	5	5.5	6	6.5	7	7.5	8	8.5	9	9.5	10	10.5	11	11.5	12
<b>MILLIMETERS</b>	232	236	240	244	248	252	256	260	264	268	272	276	280	284	288
<b>EUROPEAN</b>	37	38	39	39.5	40	40.5	41	41.5	42	42.5	43	44	44.5	45	46
<b>UK</b>	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9	9.5	10	10.5	11	11.5